




Precision Calibrated Downhaul

Our new Calibrated Downhaul System takes all of the guess work out of setting the downhaul.

Here's how it works: We rig each sail in the factory on the correct mast with a load cell (a highly accurate scale). Once the predetermined load is achieved, we mark the sail at the

exact position that aligns with the bottom of the mast. So, all you need to do is downhaul until the bottom of your mast lines up with our mark.

The calibrated downhaul system is designed to be used with Ezzy masts and is available now on the new **4 batten Panther Elite**.



ezzy.com