## EARBUDS ON

CORDED CHARGING

EARBUDS OFF

WIRELESS QI CHARGING
Charger not included

WAKE CASE
Tap the screen or press the button on back to wake charge case from sleep.

DOWNLOAD APP
Download Poly Lens App to get the most out of your wireless earbuds.

- Customize swipe features
- Change settings
- Update devices
- View user guide

↓ **poly.com/lens**

Poly Lens Mobile App
Poly Lens Desktop App

BLUETOOTH TRANSMITTER
Listen wirelessly to an inflight entertainment system or other audio source with a 3.5 mm port. Connect your case to audio port with included 3.5-mm-to-USB-C cable.

poly

QUICK START
## VOYAGER FREE 60+ UC
WITH TOUCHSCREEN CHARGE CASE

ANC / Transparency

Audio Source

BT700 Bluetooth™ adapter design may vary

CONTROLS

Button

- Use either earbud

Swipe

↕ Volume +/- for media

Mute/unmute a call

ANC/Transparency toggle when idle

- Use either earbud
- Swipe slowly
- Customize in Poly Lens App

Volume

Adjust on charge case or paired device

Streaming media only: swipe earbud


PAIR

Mobile phone | Remove earbuds from the charge case before pairing.

1.

2.

Pair Device

3.

Poly VFree 60 Series

4.

"Pairing successful, phone connected"

Computer

1.

2.

3.

"PC connected"

FIT | Rotate the earbuds toward your mouth for optimum fit and sound.

EARTIPS | Select size for comfort and bass response.

Sizes **Remove at eartip's base**   **Replace**

L

M

S

1. **2.**   **1.** **2.**